How to write active power (kW) setpoint through Modbus

Justin Schneider - 2026-10-14 - easYgen-3000XT

How to write active power (kW) setpoint through Modbus?

Example with Setpoint of 500 kW:

kW Remote Setpoint Address = 507

(This example shows the handling of the active power setpoint with PC software "ModScan32".)

1) Select the function, i.e. FC16

2) Number of Points.... -> O.K.

3) Enter the desired value.

4) Click Update.