



[ナレッジベース](#) > [easYgen-800](#) > [easYgen-800/-1800 IDMT / Ground Fault formulas](#)

easYgen-800/-1800 IDMT / Ground Fault formulas

Simon - 2021-12-15 - [easYgen-800](#)

Formulas for Overcurrent / Ground Fault

- **IDMT Multiply of Overcurrent settings formula:**
 $T = t / ((IA/IT)-1)^2$

T Overcurrent delay (seconds)

t Timing multiplier ratio

IA Current max. load current [L1/L2/L3]

IT Overcurrent setting value

Example

$$t = 36$$

$$IA = 550A$$

$$IT = 500A$$

Conclusion: $T = 3600 s$

- **Delay Multiplier for Ground Fault formula:**

ground current delay action calculation (0.1s)=delay multiplier*0.14/(((ground current/ground current threshold)^{0.02}-1)