



[Knowledgebase](#) > [DSLC-2](#) > [Can I do load sharing with DSLC-2 and DSLC-2XT ?](#)

Can I do load sharing with DSLC-2 and DSLC-2XT ?

Clemens - 2023-01-18 - [DSLC-2](#)

DSLC-2/MSLC-2 and successors DSLC-2XT/MSLC-2XT are doing load sharing via Ethernet lines.

If you want to do load sharing between old DSLC-2/MSLC-2 and new DSLC-2XT/MSLC-2XT you have to make sure that latest firmware Revision L is loaded in your DSLC-2/MSLC-2.

Latest DSLC-2/MSLC2 Firmware Revision L (partnumbers 8440-1877/-1878/-1977/-1978 can be downloaded here: https://wss.woodward.com/manuals/Support/Firmware_DSLC-2_MSLC-2

