

<u>Knowledgebase</u> > <u>easYgen-3000</u> > <u>Display Calibration easYgen-3x00 controls</u>

Display Calibration easYgen-3x00 controls

Clemens - 2024-09-27 - <u>easYgen-3000</u>

You can adjust display brightness and contrast manually via HMI

or press the STOP button for around 10 seconds, after 7 seconds, auto calibration mode is starting and after 10 seconds display is auto calibrated

