



[Knowledgebase](#) > [easYgen-3000XT](#) > [easYgen-3000XT PWM settings for CAT ADEM interfacing](#)

easYgen-3000XT PWM settings for CAT ADEM interfacing

Clemens - 2024-09-27 - [easYgen-3000XT](#)

easYgen's PWM PID output signal need to set to min 50% and max 85% (parameter 5208 and 5209) when a CAT ADEM ECM is connected.

