



[Knowledgebase](#) > [Power Management](#) > [easYgen-3000XT](#) > [software](#) > [How to license the ModbusMaster Mapper tool for the easYgen-3000XT?](#)

How to license the ModbusMaster Mapper tool for the easYgen-3000XT?

Justin Schneider - 2026-07-27 - [software](#)

ModbusMaster Mapper tool requires a license when more than one slave devices to be supported.

10-017-822

This is item number of installer file and supports 1 slave device with full read write capability.

10-017-923


This is item number for activating license. The tool then supports up to 5 Modbus/TCP slaves

Modbus Master Mapper Tool can be downloaded here:


https://wss.woodward.com/manuals/PGC/easYgen-3000XT_series/SW_Tools/ModbusMasterMapper

Modbus Master Application note


https://wss.woodward.com/manuals/PGC/easYgen-3000XT_series/Application_Notes/37919_AN_ModbusMasterMapper_A.pdf



Activate Licensing from Help menu



Put the "Site Code" in your purchase order along with licensing P/N 10-017-923



Receive "License Key" and insert it in "License Authorization" window. After a restart, the tool runs without restriction. Note: Help/Licensing disappears from a licensed version