



[Knowledgebase](#) > [Power Management](#) > [DTSC-200](#) > [I cannot get Toolkit running via DTSC-200's RS232/RJ45 COM port & DPC cable](#)

I cannot get Toolkit running via DTSC-200's RS232/RJ45 COM port & DPC cable

Justin Schneider - 2026-07-27 - [DTSC-200](#)

However obviously ToolKit cannot access the COM port or no connection to the device.

1.)

Check the Baudrate which is setup in the DTSC-200's Serial Interface #1

-through the HMI push buttons, enter Code first. e.g. 0003 or 0500, then check the baudrate if it is lower than 9600.

(ToolKit only works with baudrate ≥ 9600 kbps)

-maybe that is the issue?

2.)

ToolKit started as Administrator?

Verify with your IT department if you actually can use the USB port / COM port in anyway