



[Knowledgebase](#) > [easYgen-3000XT](#) > [Software](#) > [How to upgrade parameters of an Old easYgen-3000 configuration to the latest easYgen-3000XT configuration using Toolkit?](#)

## How to upgrade parameters of an Old easYgen-3000 configuration to the latest easYgen-3000XT configuration using Toolkit?

Simon - 2025-02-07 - [Software](#)

If you're transitioning from an old easYgen-3000 product to its latest successor, such as the easYgen-3000XT, the **Toolkit** software offers a convenient feature to simplify the process. This tool can compare the configuration settings file (.WSET) of your old product and assist in converting it for use with the new easYgen-3000XT.

Please take the attached detailed documentation into account as well. (download available below this article)

Follow the steps in the screenshots below to complete the upgrade process:



This does take a few moments. Just wait till the conversion is done, and next window shows up.

Upon successful conversion there comes this note below. A log file is generated at each conversion. Just for your reference.



Click "OK" to close.

If there is no further action needed, there comes this message:



Click "Close" and you are done.

If not all parameters could be overtaken because e.g. of a pretty old easYgen version, then there comes a notification as below.

If possible it allows to "Map" old parameters to the new version step by step. Or just click OK to check/modify the parameters directly in the wset file later.



**Attachments**

- [Conversion\\_tool\\_exceptions\\_Version4\\_Nov2020.docx \(318.38 KB\)](#)