



[Knowledgebase](#) > [Power Management](#) > [easYgen-3000](#) > [Display Calibration easYgen-3x00 controls](#)

## Display Calibration easYgen-3x00 controls

Justin Schneider - 2026-07-27 - [easYgen-3000](#)

You can adjust display brightness and contrast manually via HMI

or press the STOP button for around 10 seconds, after 7 seconds, auto calibration mode is starting and after 10 seconds display is auto calibrated

|  |                                                                                   |      |                                                                                                                                                                         |
|--|-----------------------------------------------------------------------------------|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |  | STOP | <p>Selects STOP mode (Hardware button).</p> <p>Pressing the STOP button for at least 10 seconds, restores the default display settings for brightness and contrast.</p> |
|--|-----------------------------------------------------------------------------------|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|